

FIG.1




FIG.2

				16bit	16bit
Header	MSB	MSB	MSB	MSB	
	00000000	11111111	11111111	11111111	0
	11111111	11111111	11111111	11111111	1
	11111111	11111111	11111111	00000000	2
	ClusterH	ClusterL	Sector(00h)	Mode(02h)	3
	00000000	00000000	00000000	00000000	4
	00000000	00000000	00000000	00000000	5
	“M”	“I”	“N”	“I”	6
	Disc type	Rec Power	First TNO	Last TNO	7
	Lead-out start address			Used Sectors	8
	Power calibration area start address			00000000	9
	U-TOC start address			00000000	10
	Recordable user area start address			00000000	11
Corresponding table pointer data section	00000000	P-TNO1	P-TNO2	P-TNO3	12
	P-TNO4	P-TNO5	P-TNO6	P-TNO7	13
	P-TNO248	P-TNO249	P-TNO250	P-TNO251	74
	P-TNO252	P-TNO253	P-TNO254	P-TNO255	75
	00000000	00000000	00000000	00000000	76
	00000000	00000000	00000000	00000000	77
(01h)	Start address			Track mode	78
(02h)	End address			00000000	79
(03h)	Start address			Track mode	80
	End address			00000000	81
	Start address			Track mode	82
	End address			00000000	83
Management table section (255 part tables)	Start address			Track mode	580
	End address			00000000	581
(FCh)	Start address			Track mode	582
	End address			00000000	583
(FDh)	Start address			Track mode	584
	End address			00000000	585
(FEh)	Start address			Track mode	586
	End address			00000000	587

FIG.3

Header				
MSB	MSB	MSB	MSB	
00000000	11111111	11111111	11111111	0
11111111	11111111	11111111	11111111	1
11111111	11111111	11111111	00000000	2
ClusterH	ClusterL	Sector(00h)	Mode(02h)	3
00000000	00000000	00000000	00000000	4
00000000	00000000	00000000	00000000	5
00000000	00000000	00000000	00000000	6
Marker Code	Model Code	First TNO	Last TNO	7
00000000	00000000	00000000	Used Sectors	8
00000000	00000000	00000000	00000000	9
00000000	00000000	00000000	Disc serial No	10
Disc ID		P-DFA	P-EMPTY	11
P-FRA	P-TNO1	P-TNO2	P-TNO3	12
P-TNO4	P-TNO5	P-TNO6	P-TNO7	13
Corresponding table pointer data section				
P-TNO248	P-TNO249	P-TNO250	P-TNO251	74
P-TNO252	P-TNO253	P-TNO254	P-TNO255	75
00000000	00000000	00000000	00000000	76
00000000	00000000	00000000	00000000	77
(01h)		Start address	Track mode	78
		End address	Link information	79
(02h)		Start address	Track mode	80
		End address	Link information	81
(03h)		Start address	Track mode	82
		End address	Link information	83
Management table section (255 part tables)				
(FCh)		Start address	Track mode	580
		End address	Link information	581
(FDh)		Start address	Track mode	582
		End address	Link information	583
(FEh)		Start address	Track mode	584
		End address	Link information	585
(FFh)		Start address	Track mode	586
		End address	Link information	587

FIG.4




FIG.5




FIG.6




FIG.7




FIG.8

7/11




FIG.9




FIG.10




FIG.11




FIG.12

